


Easy Set Up Instructions.

Thank you for purchasing the iPort Quiet Call™ paging system. For full detailed information, please consult the instruction manual.

System Configuration: Your Quiet Call system was programmed and charged at the factory and will function as soon as it is powered up.



Step 1

Lock the antenna to the top right corner of the Quiet Call™ transmitter. (fit over plug and twist left to lock antenna in place).

Step 2

Plug the Quiet Call™ transmitter A/C adaptor into the Quiet Call™ transmitter and then into a standard 110v outlet. A surge protector is recommended.

Step 3

If more than one charging base is used, connect base units with jumper wires. Plug the charging base A/C adaptor into charging base and then into a standard 110v outlet. A surge protector is recommended.

Step 4

Stack Quiet Call™ coasters on the chargers (max 15 high) or place pagers into the charging slots. A red or green light will illuminate to indicate charging. Pagers will be fully charged in 2 hours.

To Use

Take a Quiet Call™ Coaster / Pager off of a charger. It will flash & vibrate. To page a guest, simply enter the pager number and press "SEND" on the Quiet Call™ transmitter. The pager will flash & vibrate until it is returned to the charger.

Default set up is as follows:

- Current time is set.
- Range test is off. (Testing range is only necessary for very large properties).
- Pagers are set to vibrate & flash.
- Out of range alert is off.

This configuration should be satisfactory for most locations. Should the need arise to make any changes follow the instructions provided in the detailed instruction booklet.

If you have difficulty please call our customer service department at: **800-359-9737** and an iPort representative will be happy to walk you through the process.

iPort Communications
1566 W. Algonquin Road
#166
Hoffman Estates, IL
60195
Phone 847-359-4987